
TMC2209
File: tmc2209.kicad_sch

TMC51X0
File: tmc51x0.kicad_sch


description	microcontroller	stepper-controller	
File: tmc2209_description.kicad_sch	File: tmc2209_microcontroller.kicad_sch	File: tmc2209_stepper-controller.kicad_sch	
teensy40 File: tmc2209_teensy40.kicad_sch	mega2560 File: tmc2209_mega2560.kicad_sch	uno File: tmc2209_uno.kicad_sch	
unidirectional File: tmc2209_unidirectional.kicad_sch	unidirectional—multiple File: tmc2209_unidirectional_multiple.kicad_sch	unidirectional-multiple-address File: tmc2209_unidirectional_multiple_address.kicad_sch	unidirectional-multiple-uart File: tmc2209_unidirectional_multiple_uart.kicad_sch
bidirectional—coupled File: tmc2209_bidirectional_coupled.kicad_sch	bidirectional-coupled-multiple-address File: tmc2209_bidirectional_coupled_multiple_addr	ess.kicad_sch	bidirectional—coupled—multiple—uart File: tmc2209_bidirectional_coupled_multiple_uart.kicad_sch


MCU_RX and R1 are optional if only unidirectional communication is desired.





Must solder jumper pads on the SilentStepStick to connect both the UART and PDN pins to the PDN_UART line on the chip!


STEP, DIR, and HARDWARE_ENABLE are optional connections to the microcontroller. STEP and DIR signals may be left disconnected if only moveAtVelocity method is used. STEP and DIR signals usually come from a dedicated stepper controller, like the TMC429. HARDWARE_ENABLE may be tied to ground if only software enable is desired. Most examples assume STEP, DIR, and HARDWARE_ENABLE are not connected to the microcontroller and that HARDWARE_ENABLE is tied to ground on the TMC2209.
















RX and TX pins must be changed in the SoftwareSerial example:
const uint8_t RX_PIN = 7;
const uint8_t TX_PIN = 6;


Arduino Uno is only capable of unidirectional communication, so only TX is connected and used, but the SoftwareSerial library requires that the RX pin must be reserved and specifed.




Must solder jumper pads on the SilentStepStick to connect both the UART and PDN pins to the PDN_UART line on the chip!


STEP, DIR, and HARDWARE_ENABLE are optional connections to the microcontroller. STEP and DIR signals may be left disconnected if only moveAtVelocity method is used. STEP and DIR signals usually come from a dedicated stepper controller, like the TMC429. HARDWARE_ENABLE may be tied to ground if only software enable is desired. Most examples assume STEP, DIR, and HARDWARE_ENABLE are not connected to the microcontroller and that HARDWARE_ENABLE is tied to ground on the TMC2209.













description File: tmc51x0_description.kicad_sch	microcontroller File: tmc51x0_microcontroller.kicad_sch
tmc51x0-bob File: tmc51x0 bob.kicad.sch	tmc51x0-eval File: tmc51x0_eval.kicad_sch





teensy40 pico


File: tmc51x0_tmc51x0_eval_teensy40.kicad_sch


File: tmc51x0_tmc51x0_eval_pico.kicad_sch











 teensy40
 pico

 File: tmc51x0_tmc51x0_bob_teensy40.kicad_sch
 File: tmc51x0_tmc51x0_bob_pico.kicad_sch